



Machine and Robot in Harmony

TPS: Teach programming system

Trio Motion Technology

Trio Robotics Series

First Edition • 2018

Revision: 1.3

Trio Programming Guides are designed to aid learning of the TrioBASIC language through description and examples. Each one will cover a particular topic and discuss which commands and parameters in the TrioBASIC are required to complete the task.

A general understanding of TrioBASIC is required and it is recommended to attend an introduction to TrioBASIC training course. The programming guides are not a replacement for the TrioBASIC help files which can be found in *Motion Perfect* as well as the manual which cover each command and parameter in more detail and should be referenced when required.

Any examples given in the programming guide will work and have been tested on an isolated controller. If you choose to use these examples on a machine please take care that it will not cause damage or injury and that they are correctly included in the project changing parameters and values where required.

All goods supplied by Trio are subject to Trio's standard terms and conditions of sale.

The material in this manual is subject to change without notice. Despite every effort, in a document of this scope errors and omissions may occur. Therefore Trio cannot be held responsible for any malfunctions or loss of data as a result.

Copyright (C) 2000-2018 Trio Motion Technology Ltd. All Rights Reserved

UK | USA | CHINA | INDIA

www.triomotion.com

SAFETY WARNING

During the installation or use of a control system, users of Trio products must ensure there is no possibility of injury to any person, or damage to machinery.

Control systems, especially during installation, can malfunction or behave unexpectedly.

Bearing this in mind, users must ensure that even in the event of a malfunction or unexpected behaviour the safety of an operator or programmer is never compromised.

This document uses the following icons for your reference:



Information that relates to safety issues and critical software information.



Information to highlight key features or methods.



Useful tips and techniques.



Example programs.

Contents

1	TPS Teach pendant	1
2	The device	1
2.1	Introduction	1
2.2	Technical specifications	3
3	Declaration of conformity	5
4	TPS: Teach Programming System	6
4.1	Virtual Teach Pendant casing	6
4.2	Keypad	7
4.3	Home screen	10
4.4	Warning / error window	11
4.4.1	Status	11
4.4.2	Log	11
4.4.3	Drive	12
4.5	Speed	14
4.6	Jog modes	15
4.7	Status bar	15
4.8	User levels	16
4.9	Main menu	18
4.10	GTAs	21
4.11	Tools dimensions	23
4.12	Tools collision	28
4.13	Object Frames	29
4.14	Robot Frames	32
4.15	Collision objects	34
4.16	Applications: Palletizer	36
5	Projects and programs	40
5.1	Project manager	40
5.2	Program editor	41
5.3	Multi-line selection	42
5.4	Default move values	42
5.5	Program types and projects	43

5.6	Instructions set	45
5.6.1	Teach	45
5.6.2	Move	45
5.6.3	Base	46
5.6.4	Gosub	47
5.6.5	Label	47
5.6.6	Stop	48
5.6.7	Empty line	48
5.6.8	Set	48
5.6.9	Wait	50
5.6.10	Structures	50
5.6.11	APPS	52
6	Settings	54
6.1	About	54
6.2	IO configuration	55
7	Error and warning codes	56
7.1	Axis status codes	56
7.2	Robot status codes	56
7.3	TPS system codes	57
7.4	RPS Architecture codes	58

1 TPS Teach pendant

The Teach Programming System allows programming the robot in a managed and safe environment, using a real or virtual system.

The pendant is based around Trio's UNIPLAY HMI and can be used as a "real" or "virtual" on-screen pendant. The system includes extensive software and preconfigured motion control functions, which permit the controlling of all standard types of robot with reduced development time.

2 The device

2.1 Introduction

A teach pendant is a device by which an operator can jog a robot and create programs in a friendly and easy way. Thanks to its safety features and buttons it is completely secure to control a robot in a safe environment.



Figure 2-1: Teach pendant device

A virtual teach pendant has been developed that, along with other Motion Perfect robot tools, provides a virtual robot environment to design and debug robot solutions over PC.




Figure 2-2: Virtual pendant

2.2 Technical specifications




Figure 2-3: teach pendant device specs

Processor	32 bit RISC Cortex	Safety Hardware	Front mounted 3 position E-Stop. 2 x rear mounted 3 position enable switch.
Memory	512 MB DDR		
Micro SD card	Up to 32 Gb	Protection Rating	IP65
Display	8" (640 x 800) touch screen	Input Voltage	24V DC via junction box (included)
Pendant Software	Windows CE Embedded 7	Size (w x d x h) mm	276.6 x 53 x 238.6
Membrane Keys	31 user definable keys (with Motion Perfect 4)	Weight	2kg
Communication	Ethernet USB 2.0	Cable	5m 26 pin shell type. RoHS compliant (connects to supplied junction box)
Stylus	Included		




Figure 2-4: Junction Box

RPS has to be configured depending on what inputs had been used to connect the junction box with the controller.

Refer to section [IO configuration](#) to set the inputs numbers into the system.

3 Declaration of conformity

This declaration of conformity is issued under the sole responsibility of the manufacturer.

We declare that the following product is in conformity with the essential requirements of the following European Council Directives.

The object of the declaration described above is in conformity with the relevant European Union harmonisation legislation in accordance with BS EN 50581:2012 and BS EN 17050-1:2010.

- Directive 2011/65/EU of the European Parliament and of the Council of 8 June 2011 on the restriction of the use of certain hazardous substances in electrical and electronic equipment ⁽¹⁾
- Directive 2014/30/EU of the European Parliament and of the Council of 26 February 2014 on the harmonisation of the laws of the Member States relating to electromagnetic compatibility ⁽²⁾.
- EN55032:2015/AC: 2016 - Electromagnetic compatibility of multimedia equipment. Emission Requirements.
- EN55024:2010 - Information technology equipment. Immunity characteristics. Limits and methods of measurement.
- IEC 61000-4-2, 2nd Edition, Dec 2008 - Electromagnetic compatibility (EMC) - Part 4-2: Testing and measurement techniques - Electrostatic discharge immunity test.
- IEC 61000-4-3, 3.2 Edition, Console with AMD 2, April 2010 - Electromagnetic compatibility (EMC) - Part 4-3: Testing and measurement techniques - Radiated, radio-frequency, electromagnetic field immunity test.
- IEC 61000-4-4, 3rd Edition, Apr 2012 - Electromagnetic compatibility (EMC) - Part 4-4: Testing and measurement techniques - Electrical fast transient/burst immunity test.
- IEC 61000-4-5, 3rd Edition, May 2014 - Electromagnetic compatibility (EMC) - Part 4-5: Testing and measurement techniques - Surge immunity test.
- IEC 61000-4-6, 4th Edition, Oct 2013 - Electromagnetic compatibility (EMC) - Part 4-6: Testing and measurement techniques - Immunity to conducted disturbances, induced by radio-frequency fields.
- IEC 61000-4-8, 2nd Edition, Sept 2009 - Electromagnetic compatibility (EMC) - Part 4-8: Testing and measurement techniques - Power frequency magnetic field immunity test.

The notified body: Compliance Certification Services Inc. Kunshan Laboratory, Kunshan City, Jiangsu, China, duly issued the CE EMC Test certificate.

Report Number: C180913E14-ET

Dated: 27th September 2018

4 TPS: Teach Programming System

4.1 Virtual Teach Pendant casing

Virtual Teach Pendant with compact casing and key switch, E-Stop and demand buttons can simulate the same behaviour like real Teach Pendant. Key switch, E-Stop and demand buttons can be configured with a virtual or real outputs. In the case of real controller, those outputs should be wired to the inputs selected for the real buttons, so the actions will be triggered either with real or virtual Teach Pendant. In the case of Simulator controller, virtual inputs and outputs are assigned to the same numbers, triggering the correct actions using inputs or outputs.

The output configuration in virtual Teach Pendant can be found in the left top menu under “Tools -> Options”. Then, under “Casing” tab, “Compact casing for HTS-A013-1C6 with key, emergency and demand button” casing option can be selected. “Enable I/O mappings” has to be selected as well, along with the desired output numbers.




Figure 4-1: virtual pendant output mappings

4.2 Keypad



Figure 4-2: menu keypad








	User interface	Enter the home page of user defined interface
	Settings	Enter the settings interface page
	Variable list	Enter the variable list page
	Program list	Prompt the list of programs in the current project
	Program editor	Enter the program editor page
	Positions	Prompt axis position window
	Messages / Log	Prompt the messages and log interface








Figure 4-3: function keypad

F1	Function key 1	Reserved
F2	Function key 2	Reserved
Mot	Motor enable	Servo ON and OFF
Rob	Robot selection	Select different robot
Jog	Coordinate system selection	Change the jog coordinate system
F/B	Forward/Backward execution	Execute the selected program forward or backward
Step	Operation mode	Change the program running mode between step and continuous mode
V-	Jog speed minus	Decrease the global jog speed
V+	Jog speed plus	Increase the global jog speed



Figure 4-4: axis keypad

	Stop program	Stop program and robot execution
	Execute program	<p>Manual mode: In <i>step mode</i>, program will step a line when button is pressed; in <i>continuous mode</i>, program will start running when button pressed and hold, and will pause when released.</p> <p>Auto mode: In <i>step mode</i>, program will step a line when button is pressed; in <i>continuous mode</i>, program will start running when button pressed.</p>
	Jog axis negative	Under servo ON condition, jog axis backward
	Jog axis positive	Under servo ON condition, jog axis forward
	Extra axes page	Change to second axis page if the robot have more than six axis

4.3 Home screen

System status windows will show warnings and errors that happens in every robot axis. It will show the axis number, error code and the message itself.






Figure 4-5: Home page

4.4 Warning / error window

If an error or warning exists, system log and status button will change its colour to yellow warning .

4.4.1 Status

The status is divided in System and Joints. General System errors or warnings will be shown under System tab. Individual Joint errors or warnings will be shown under each Joint tab.

Errors can try to be cleared by pressing refresh button .




Figure 4-6: System status window

 Please, refer to [Error and warning codes](#) section for a full list.

4.4.2 Log

The log window will show and store warning and error messages. Up to 2048 messages will be stored in flash memory. The messages will be compound by date and time of message generation, number of seconds the controller is active and the message itself.

The whole group of messages can be cleared by clicking trash button.

A special log entry is stored every time the controller is powered up, such as:

```
600:00014@1ms[0.05 2.0296000 $0000 $0c000003]
```

600 = Controller type
 00014 = Controller serial number
 @1ms = Servo period cycle time
 0.05 = Bootloader version
 2.0296000 = Firmware version
 \$0000 = FPGA number
 \$0c000003 = Feature Enabled Codes




Figure 4-7: System log window

4.4.3 Drive

Users can develop their own logic to catch Drive errors and send messages to the teach pendant under Drive tab.

To show a user drive error on teach pendant, VR(DriveError) has to be = 1.

To reset it to its normal status, VR(DriveError) has to be = 0.

To trigger the events, VR(DriveMessageTrigger) has to be incremented.

The messages have to be stored in VRs and have been divided by axis: VR(DriveMessageAxis1), VR(DriveMessageAxis2), VR(DriveMessageAxis3), VR(DriveMessageAxis4), VR(DriveMessageAxis5) and VR(DriveMessageAxis6).



To clear the messages from the Drive window, the refresh button has to be pressed. This action will turn the flag `VR(DriveErrorReset) = 1`. The user will have to handle in his logic the drive error reset procedure and clear all VRs error messages. The window will be clear automatically after press refresh button, so `VR(DriveMessageTrigger)` should be triggered if some errors persist after the reset procedure.

Example:

```
INCLUDE "RPS_A_INITIALISE_VARIABLES"

'Trigger error flag, so it will highlight status icon on pendant
VR(driveerror) = 1
'Set error messages:
VR(drivemessageaxis1) = "Error in drive 1"
VR(drivemessageaxis3) = "Error in drive 3"

'Trigger drive errors:
VR(drivemessagettrigger) = VR(drivemessagettrigger) + 1

'Reset errors:
'press refresh button -> VR(DriveErrorReset) = 1
IF VR(driveerrorreset) = 1 THEN
    VR(driveerrorreset) = 0

    'Reset logic:
    'error drive 1 persist
    VR(drivemessageaxis1) = "Error in drive 1 persist"
    'error drive 3 cleared
    VR(drivemessageaxis3) = 0

    'Trigger drive errors
    VR(drivemessagettrigger) = VR(drivemessagettrigger) + 1
ENDIF
```




Figure 4-8: Drive error window

4.5 Speed

Jog speed can be set in percentages by Speed window.



Figure 4-9: Speed window

4.6 Jog modes

There are five different jog modes selectable sequentially by pressing Jog mode button. The button will change its icon accordingly with selected mode.

	Joint	Each axis moves independently. The robot arm moves around joint under demand range. The position of end-effector is determined by joint orientation and position.
	World	The end-effector moves straight along the world coordinate system. The orientation use extrinsic rotations. All the position of end-effector is defined by world coordinate. It is possible that singularity point will occur when using world coordinate.
	Base	The end-effector moves straight along the base coordinate system. The orientation use extrinsic rotations. The origin point of the system is on the robot base.
	Tool	The end-effector moves straight along the tool coordinate system. The orientation use intrinsic rotation. The origin point of the system is on the tool like gripper.
	Object Frame	The end-effector moves straight along the active object frame. The orientation use extrinsic rotations.

4.7 Status bar




Status bar will show the robot, tool, object frame and robot frame selected. All of them are selectable in their specific pages.



Figure 4-10: status bar

It is also shown the status of pendant (manual, auto, disabled), Estop, Servo and Demand buttons.

	Manual, Auto, Disabled mode
	Estop released, Estop pressed
	Servo ON, Servo OFF

	Demand button released, Demand button pressed
	Step mode
	Continuous mode

4.8 User levels

The system will enable or disable different features depending on the selected user level. There are four user levels as described below:

Level 1: Highest level with all authority in the system, all the functions and features are available. It has been designed mainly for developers.

Level 2: Manufacturing level. For now, level 2 and level 1 share almost the same authority in the system.

Level 3: Customer engineering level. In this level users will not be allowed to configure system information or change system configuration.

Level 4: This level is designed for operators who work around the robot. Only run edited programs and start/stop/shut down the system or programs functions are available.

Feature	Level 1	Level 2	Level 3	Level 4
Status and log	Y	Y	Y	Y
Jog Speed	Y	Y	Y	N
Jog Modes	Y	Y	Y	N
GtAs	Y	Y	Y	N
Tools Dimensions	Y	Y	Y	N
Tools Collision	Y	Y	Y	N
Object Frames	Y	Y	Y	N
Robot Frames	Y	Y	Y	N
Collision Objects	Y	Y	Y	N
Project Manager	Y	Y	Y	Y
Program Editor(Debug Buttons)	Y	Y	Y	Y
Program Editor(Program edition Buttons)	Y	Y	Y	N
Program Types and Projects	Y	Y	Y	Y
Instructions Set	Y	Y	Y	N
Settings	Y	Y	N	N

IOs settings	Y	Y	N	N
--------------	---	---	---	---

User level status. It is a button that shows the current user level and shows the user level window when pressed.



Figure 4-11: user level status button

The levels can be set through user level window. Higher level can set a lower level without password. To set a higher level than the current one the correct password has to be set.





Figure 4-12: user level window

To change the password of a level, the button  has to be pressed.

It is only possible to change the password of a level from its level or higher.

Default passwords are as follows:

- Level 1: level1
- Level 2: level2
- Level 3: level3
- Level 4: level4

Characters allowed are the ASCII table.

To reset all passwords to default values, COORDINATOR_DATA(68) instruction has to be executed over the terminal through Motion Perfect.










Figure 4-13: change level password window

4.9 Main menu


Main menu button will drop the main menu:

 Projects	Projects manager and program editor
 GTAs	GTA page
 Tools & Frames	Tools and Frames menu
 Applications	Applications menu
 I/O	Inputs / outputs page
 Settings	Setting page

Projects:


	  	
 Projects	 Load/Save	Project manager window
 GTAs	 Editor	Program editor page

Applications:



Palletizer page

Tools, frames and collision objects:























Object Frames page

Robot Frames page

Tools menu

Collision Objects page

Tools dimensions and collision:

	      	
 Projects		
 GTAs		
 Tools & Frames	 Object Frames	
 Applications	 Robot Frames	
 I/O	 Tools	 Dimensions
 Settings	 Collision Objects	 Collision

Tools dimension page
Tools collision page

4.10 GTAs

GTA is the Global Targets Array which contains an array of globally available TARGET points.

It stores information of position and orientation in 3D space. The TARGET data type represents a set of 6 values:

- X, Y, Z – for the coordinates of the point in 3D space in millimetres
- U, V, W – for the angular orientation in degrees.



An array of 1000 GTAs is available for use in all programs. In addition to the 6 coordinates GTAs can have name assigned which can be used to reference them in programs.

Index	Name	X	Y	Z	U	V	W
0	pt1	350.000	0.000	515.000	180.000	80.000	180.000
1	pt2	380.001	0.000	514.997	-110.000	40.000	-120.000
2	pt3	400.001	0.000	514.997	-139.966	40.227	-142.582
3	pt4	420.001	0.000	514.997	100.000	49.335	120.000
4		420.000	0.000	515.000	180.000	70.000	180.000
5		420.000	0.000	515.000	180.000	40.000	180.000
6	pt6	350.001	43.800	550.897	180.000	59.049	180.000
7	pt7	214.076	43.800	550.897	166.330	39.225	-160.765
8	pt8	214.076	131.900	550.897	-173.207	31.272	-148.843
9	pt9	267.245	149.414	461.061	-170.471	-30.617	-0.010
10	pt10	167.158	149.414	461.061	-131.340	-24.652	-18.757
11							
12							
13							
14							
15							
16							
17							
18							
19							
20							
21							
22							
23							
24							
25							


World	mm/s
X	350.00
Y	0.00
Z	515.00
U	180.00
V	80.00
W	180.00

Joint	°/s
J1	0.00
J2	3.80
J3	-6.25
J4	0.00
J5	12.45
J6	0.00

Figure 4-14: GTA page

	Save
	Refresh


On this screen you can see the range of GTAs that are in controller volatile memory at the moment of entry in this page. All the changes will be done in volatile memory. It is possible to save the whole table in flash memory by clicking save button. It will save the table in the program “ROBOT_GLOBAL_TARGETS” (the program will be overwritten with the new values). If a GTA is set by another program while GTA page is active, it is possible to refresh the table by clicking refresh button.



Move to GTA button will move the robot to the selected GTA with the active tool and frames, at the selected speed and mode.




Teach button will store the current position in the selected GTA with a given name. The position can be changed by jogging the robot with jog buttons of the Teach Pendant.



Shift up and down buttons will effectively shift a selected GTA on position in the list.



Edit button will prompt an editor by which the operator can directly type-in a new GTA or modify the coordinates or the name of a previously defined entry.



It is possible to delete a GTA (or a range of GTAs by having *Multi select* check box checked) by clicking in delete button. That entry will become empty in controller volatile memory and GTAs screen but controller program will still having the entry until save button is pressed.

Zero entries check box will collapse or expand the empty entries for a more compact representation.




Figure 4-15: Edit GTAs window

4.11 Tools dimensions

The tool offset is a transformation between the end-effector and the Tool Centre Point. It sets a distance and orientation of a tool from the end effector to the TCP.



Similar to the target points it is presented as a set of 6 values:

- X, Y, Z – for the coordinates of the offset in millimetres
- U, V, W – for the angular orientation of the tip in degrees.


An array of 31 tool definitions is available for use to all programs. Unique name can be assigned to each tool to be used to identify and reference it in programs.

Index	Name	X	Y	Z	U	V	W
0	Default	0.000	0.000	0.000	0.000	0.000	0.000
1	Gripper	5.000	0.000	100.000	0.000	0.000	0.000
2	Torch	6.294	-0.423	271.315	0.000	0.000	0.000
3							
4							
5							
6							
7							
8							
9							
10							
11							
12							
13							
14							
15							
16							
17							
18							
19							
20							
21							
22							
23							
24							
25							

Figure 4-16: Tools page

	Save
	Refresh


On this screen you can see the range of Tools that are in controller volatile memory at the moment of entry in this page. All the changes will be done in volatile memory. It is possible to save the whole table in flash memory by clicking save button. It will save the table in the program “ROBOT_TOOLS_AND_FRAMES” (the program will be overwritten with the new values). If a Tool is set by another program while Tools page is active, it is possible to refresh the table by clicking refresh button.




It is possible to activate the selected Tool by clicking Select button. The selected tool will be highlighted in green colour. Tool offset 0 is active by default.



Edit button will prompt an editor by which the operator can directly type-in a new Tool dimension or modify the coordinates or the name of a previously defined entry.



It is possible to delete a Tool (or a range of Tools by having *Multi select* check box checked) by clicking in delete button. That entry will become empty in controller volatile memory and Tools Dimensions screen but controller program will still having the entry until save button is pressed.



Calibrate button will lead to Calibrate page. In this page it will be possible to calculate the dimensions of a tool performing a calibration procedure.







Figure 4-17: Tool calibration page

	Calibrate
	Accept
	Cancel

During the calibration procedure the robot has to be moved to different positions and orientations trying to keep the tip of the tool as close as possible to a pre-selected point in 3D space. Usually a calibration object is fixed in a stable position relative the robot so that it can be used as a reference point.

The operator should jog the robot position and orientation until the tip goes as close as possible to the reference object.

By pressing one of the grey tools images the values will be saved for that position and it will become green, showing that position has been stored.




Figure 3-18: Tool calibration save position window




Figure 3-19: Tool calibration one position saved

Then the operator can continue by capturing the next point.

Once four points are captured the system will enable calibration button and, after this button had been pressed, calibration algorithm will attempt to calculate the tool offset based on the input points that are collected.

A deviation value (Serror) is displayed as well. It can be used as an indication for the quality of the point and the operator can decide to recapture some of the points in order to improve the calibration.




Figure 4-20: Tool calibration process done

By pressing accept button the tool data will be stored to the controller and the new values will appear in Tools page.

Tool Offsets							
Index	Name	X	Y	Z	U	V	W
0	Default	0.000	0.000	0.000	0.000	0.000	0.000
1	gripper	50.000	0.000	100.000	0.000	0.000	0.000
2	torch	48.308	0.135	162.825	0.000	45.000	0.000
3							
4							
5							
6							
7							
8							
9							
10							
11							
12							
13							
14							
15							
16							
17							
18							
19							
20							
21							
22							
23							
24							
25							

World mm/s	
X	350.00
Y	0.00
Z	515.00
U	180.00
V	80.00
W	180.00

Joint °/s	
J1	0.00
J2	3.80
J3	-6.25
J4	0.00
J5	12.45
J6	0.00

Figure 4-21: Tools page calibration process done

4.12 Tools collision


The tool collision is an Oriented Bounding Box around the physical tool. It sets the centre position of the OBB and the dimensions needed for the collision algorithm.

It is presented as a set of 6 values:

- CX, CY, CZ – centre position of the OBB on the object in millimetres
- DX, DY, DZ – half distances measured in every vector of the OBB in millimetres.

Tools collision is information stored in tool data, which means rules of tools offset apply here. An array of 31 definitions is available for use to all programs. A unique name can be assigned to each tool to be used to identify and reference it in programs.

 For more information please, refer to RPS manual.



Tool Collision							
Index	Name	CX	CY	CZ	DX	DY	DZ
0	Default	0.000	0.000	0.000	0.000	0.000	0.000
1	Gripper	0.000	0.000	75.000	50.000	50.000	50.000
2	Torch	0.000	0.000	150.000	50.000	50.000	50.000
3							
4							
5							
6							
7							
8							
9							
10							
11							
12							
13							
14							
15							
16							
17							
18							
19							
20							
21							
22							
23							
24							
25							

World mm/s	
X	350.00
Y	0.00
Z	515.00
U	180.00
V	80.00
W	180.00

Joint °/s	
J1	0.00
J2	3.80
J3	-6.25
J4	0.00
J5	12.45
J6	0.00

Zero entries

Figure 4-22: Object Frames page

4.13 Object Frames

The object frame is a transformation between the global coordinate system and the coordinate system of an object that is manipulated by the robot. By using object frames it is possible for target points to be defined with respect in the coordinate system of the object. Similar to the target points it is presented as a set of 6 values:

- X, Y, Z – for the coordinates of the offset in millimetres
- U, V, W – for the angular orientation offset in degrees.

An array of 31 object frame definitions is available for use to all programs. A unique name can be assigned to each object frame to be used to identify and reference it in programs.



Object Frames							
Index	Name	X	Y	Z	U	V	W
0	Default	0.000	0.000	0.000	0.000	0.000	0.000
1	Camera	400.000	100.000	520.000	0.000	90.000	0.000
2							
3							
4							
5							
6							
7							
8							
9							
10							
11							
12							
13							
14							
15							
16							
17							
18							
19							
20							
21							
22							
23							
24							
25							

World mm/s	
X	350.00
Y	0.00
Z	515.00
U	180.00
V	80.00
W	180.00

Joint %/s	
J1	0.00
J2	3.80
J3	-6.25
J4	0.00
J5	12.45
J6	0.00


Zero entries

Figure 4-23: Object Frames page


	Save
	Refresh

On this screen you can see the range of Object Frames that are in controller volatile memory at the moment of entry in this page. All the changes will be done in volatile memory. It is possible to save the whole table in flash memory by clicking save button. It will save the table in the program “ROBOT_TOOLS_AND_FRAMES” (the program will be overwritten with the new values). If an Object

Frame is set by another program while Object Frames page is active, it is possible to refresh the table by clicking refresh button.



It is possible to activate the selected Object Frame by clicking Select button. The selected object frame will be highlighted in green colour. Object frame 0 is active by default.



Edit button will prompt an editor by which the operator can directly type-in a new Object Frames or modify the coordinates or the name of a previously defined entry.



It is possible to delete an Object Frame (or a range of frames by having *Multi select* check box checked) by clicking in delete button. That entry will become empty in controller volatile memory and Object Frames screen but controller program will still having the entry until save button is pressed.



Teach button will prompt the constructor window. In Object Frame constructor window it will be able to build an Object Frame by teaching three points as follows:

- First point should be at the base or the origin of the object coordinate system.
- Second point should on the X axis of the object coordinate system.
- Third point should on the Y axis of the object coordinate system.




Figure 4-24: construct Object Frame window

Points are captured using Teach Pendant jog buttons.

The operator should adjust the robot position and orientation until the tip goes as close as possible to the desired target point.

The corresponding button changes its state if the captured point is correct.

When three points are captured the object frame is ready to be stored and the operator can select a unique name for it so that it can be referenced in programs.

Edit button will prompt an editor by which the operator can directly type-in a new Object Frame or modify the coordinates or the name of a previously defined entry.

It is possible to delete an Object Frame by clicking in delete button. That entry will become empty in controller volatile memory and Object Frame screen but controller program will still have the entry until save button is pressed.

Zero entries check box will collapse or expand the empty entries for a more compact representation.




Figure 4-25: Edit Object Frames window

4.14 Robot Frames

The robot frame is a transformation between the global coordinate system and the coordinate system of the robot. By using robot frames it is possible for multiple robots to be positioned with regard to a common global coordinate system. Similar to the target points robot frames are presented as a set of 6 values:

- X, Y, Z – for the coordinates of the offset in millimetres
- U, V, W – for the angular orientation offset in degrees.

An array of 31 robot frame definitions is available for use to all programs. Unique name can be assigned to each robot frame to be used to identify and reference it in programs.



Index	Name	X	Y	Z	U	V	W
0	Default	0.000	0.000	0.000	0.000	0.000	0.000
1	robot1	1000.000	500.000	0.000	0.000	0.000	0.000
2							
3							
4							
5							
6							
7							
8							
9							
10							
11							
12							
13							
14							
15							
16							
17							
18							
19							
20							
21							
22							
23							
24							
25							

World mm/s	
X	350.00
Y	0.00
Z	515.00
U	180.00
V	80.00
W	180.00


Joint °/s	
J1	0.00
J2	3.80
J3	-6.25
J4	0.00
J5	12.45
J6	0.00

Zero entries

Figure 4-26: Robot Frames page

	Save
	Refresh

On this screen you can see the range of Robot Frames that are in controller volatile memory at the moment of entry in this page. All the changes will be done in volatile memory. It is possible to save the whole table in flash memory by clicking save button. It will save the table in the program “ROBOT_TOOLS_AND_FRAMES” (the program will be overwritten with the new values). If a Robot Frame is set by another program while Robot Frames page is active, it is possible to refresh the table by clicking refresh button.



It is possible to activate the selected Robot Frame by clicking Select button. The selected Robot frame will be highlighted in green colour. Robot frame 0 is active by default.



Edit button will prompt an editor by which the operator can directly type-in a new Robot Frame or modify the coordinates or the name of a previously defined entry.





Figure 4-27: Edit Robot Frames window



It is possible to delete a Robot Frame by clicking in delete button. That entry will become empty in controller volatile memory and Robot Frame screen but controller program will still having the entry until save button is pressed.

Zero entries check box will collapse or expand the empty entries for a more compact representation.

4.15 Collision objects

Collision objects are an Oriented Bounding Boxes around the physical objects present in the scenario. It sets the centre position and orientation of the OBB and the dimensions needed for the collision algorithm.

It is presented as a set of 9 values:

- X, Y, Z – centre position of the OBB on the object in millimetres
- U, V, W – centre orientation of the OBB on the object in degrees
- DX, DY, DZ – half distances measured in every vector of the OBB in millimetres.

An array of 32 definitions is available for use to all programs. A unique name can be assigned to each object to be used to identify.



Collision Objects										
Index	Name	CX	CY	CZ	CU	CV	CW	DX	DY	DZ
0	object0	350.000	0.000	50.000	0.000	0.000	0.000	50.000	50.000	50.000
1	object1	450.000	0.000	400.000	0.000	0.000	0.000	50.000	50.000	50.000
2										
3										
4	object4	350.000	200.000	10.000	0.000	0.000	0.000	80.000	80.000	80.000
5										
6										
7										
8										
9										
10										
11										
12										
13										
14										
15										
16										
17										
18										
19										
20										
21										
22										
23										
24										
25										

World mm/s	
X	350.00
Y	0.00
Z	515.00
U	180.00
V	80.00
W	180.00

Joint °/s	
J1	0.00
J2	3.80
J3	-6.25
J4	0.00
J5	12.45
J6	0.00


Zero entries

Figure 4-28: Collision Objects.

	Save
	Refresh

On this screen you can see the range of Collision Objects that are in controller volatile memory at the moment of entry in this page. All the changes will be done in volatile memory. It is possible to save the whole table in flash memory by clicking save button. It will save the table in the program "ROBOT_TOOLS_AND_FRAMES" (the program will be overwritten with the new values). If a Collision

Object is set by another program while Collision Objects page is active, it is possible to refresh the table by clicking refresh button.



It is possible to activate the selected Collision Objects by clicking Select button. The selected Collision Objects will be highlighted in green colour.

Although is possible to define 32 Collision Objects, just 10 can be active at the same time.

Each object is activated per robot defined. It means an object can be active for a robot and not for other existing one in the system.



Edit button will prompt an editor by witch the operator can directly type-in a new Collision Objects or modify the coordinates or the name of a previously defined entry.





Figure 4-29: Edit Collision Object window.



It is possible to delete a Collision Object by clicking in delete button. That entry will become empty in controller volatile memory and Collision Objects screen but controller program will still having the entry until save button is pressed.

4.16 Applications: Palletizer

This function can create a palletizer. It separates the building process into several steps.

The first step builds a plane with size of three dimensions.




Figure 4-30: pallet configuration window.

The second step is to design item size and position. The dimension of item and position of tool target.




Figure 4-31: item configuration window

The third step is to design number items of each layer.




Figure 4-32: layer configuration step1 window

The objects on each layer can be organised by clicking Edit in Layer configuration page.




Figure 4-33: item organiser window

The next step can put items on a virtual tray.





Figure 4-34: layer configuration step2 window

The Generate Points button can define the start number from GTAs list.



There is another application related to this palletizer application in pendant edit program list.

5 Projects and programs

5.1 Project manager

Projects and programs can be handled through project manager window.





Figure 5-1: project manager window

In this manager it is possible to save programs and projects into an USB stick connected to the teach pendant if the controller button is selected.

If USB stick button is selected, its content is shown and programs and projects can be loaded or deleted.

 Only one project with multiples programs can be stored in controller memory. For multiples projects use an USB stick. Projects have to be in root directory organised in folders.

5.2 Program editor

In program editor page is where a program can be edited and it provides debugging facilities for robot programs.
















Figure 5-2: Program editor page

Debug buttons:

	Run	Run selected program.
	Stop	Stops selected running program.
	Motion stop	Stops all currently running programs and empties all move buffers causing all motion to stop.
	Break point	Toggle breakpoint on selected line.

Program edition buttons:

	Program list	Prompt the list of robot programs and the actions that can be done to them.
	Indent	It will auto-format the program for a more readable form.
	Comment	Comment and uncomment selected lines, group of lines or insert comment in line.
	Insert above	Shows the instruction list to be inserted above the selected line.
	Insert below	Shows the instruction list to be inserted below the selected line.
	Edit	It will prompt the corresponding window depending on the selected instruction to edit.
	Copy / Cut / Paste	The selected line or multiple lines can be copied, cut or pasted using this menu button.
	Delete	Delete the selected line or multiple lines.

5.3 Multi-line selection

On the right lower corner there is a **Multi select** check box that allows up to 20 lines be selected at the same time. It is possible to copy, cut, paste, delete and comment the selected group of lines at the same time.

5.4 Default move values

Default move values can be accessible by the left lower corner link where, in this case, says **MOVEJ S:=50 T:=TO_default O:=OF_default**. These values will be used by teach instruction explained below.





Figure 5-3: default move window

5.5 Program types and projects

The *program list* button  will prompt the program list window and what can be done to them. It shows in a list all robot programs available in controller flash memory.

There are two different robot programs: Robot Programs (.ROB file extension) and Robot Basic Programs (.RBS file extension).




Figure 5-4: program list window

Both have the same functionality but robot programs can only contain the list of functions available from pendant. Also, TPS can only edit robot programs. Robot basic programs can only be run and debugged. To select what type of robot program will be shown in the program list just simply press the buttons:





Figure 5-4: robot program type

It is possible to edit, duplicate, rename or delete a robot program or robot basic program selecting it on the list and pressing the corresponding button.

To create a new robot program simply press **New** button and assign a unique name.

Robot basic program can only be seen if the system is in the correct level.



The picture below shows a blank new program called “PICK_AND_PLACE”:

To change the name of the project just simply press over the current project name, “MyRobotProject” in this case, and a keypad will be prompt.

Figure 5-6: program PICK_AND_PLACE recently created

5.6 Instructions set

A certain group of instructions can be inserted above or below of the selected line by clicking *insert above* and *insert below* buttons.




Figure 5-7: Instruction list menu

5.6.1 Teach

It is possible to speed up the process of inserting several moves of the same type and the same parameters. In this case the GTA coordinates are captured from the current robot position instead of from the GTA table. The coordinates are saved automatically in the next empty GTA starting from the selected index in default move values window.

5.6.2 Move

Up to three move instructions can be inserted with move instruction window.

MOVEJ is used to move the robot from one point to another along a non-linear path. All axes reach the destination position at the same time. It is the quickest type of movement due to the axes move the exact amount of degrees needed to reach the desired position.

MOVEL is used to move the robot from one point to another along a linear path. All axes reach the destination position at the same time.

MOVEC is used to move the robot from one point to another along a circular path. All axes reach the destination position at the same time. This type of move needs a middle point in the curve and the end point.




Figure 5-8: MOVE instruction window

It is possible to modify the behaviour of the movement according to some embedded parameters. These parameters only affect the belonging move instruction. If a move instruction has no parameter or just a few it will use the default values for any missing parameter. The available parameters are:

- S: Speed in degrees per second for joint moves and millimetres per second for linear and circular moves.
- T: Tool offset.
- O: Object Frame.
- C: Configuration (just for joint moves).
- Z: Precision (just for linear moves).

Use the current robot position storing the data into a GTA is possible through Teach button. If a GTA is selected, the system will reteach it with the new axis values, otherwise the system will store the values in a no active GTA, starting from the selected default index ([4.4 Default move values](#)).

After apply the changes, the system will store the data in both, controller volatile memory and in ROBOT_GLOBAL_TARGETS file.

On the other hand, if cancel button is pressed, all the changes will be discarded.



If a GTA is already selected, Teach button will overwrite its value with the current robot position.

5.6.3 Base

The BASE command is used to direct all subsequent motion instructions and robot parameter read/writes to a particular robot. It is also used to select external axes.

Therefore, the first axis number of the robot is going to be selected will be needed, as well as external axis number.

```
Selected project: MyRobotProject
Selected program: PICK_AND_PLACE

0 BASE(1)
1
```

Figure 5-9: BASE instruction

5.6.4 Gosub

Stores the position of the line after the GOSUB command and then branches to the label specified. Upon reaching the RETURN statement, control is returned to the stored line.

GOSUB structure can be nested up to 8 deep in each program.

```
Selected project: MyRobotProject
Selected program: PICK_AND_PLACE

0 BASE(1)
1 GOSUB my_label
2
```

Figure 5-10: GOSUB instruction

5.6.5 Label


Labels are used as destinations for GOSUB commands and also to aid readability of code.

With a label RETURN instruction is inserted automatically as well. RETURN instruction can be inserted as its own by selecting RETURN radio button on LABEL window.

```
Selected project: MyRobotProject
Selected program: PICK_AND_PLACE

0 BASE(1)
1 GOSUB my_label
2
3 my_label:
4 RETURN
5
```

Figure 5-11: Label instruction

 It is recommended to insert STOP instruction above any LABEL-RETURN structure to avoid execution errors.

5.6.6 Stop

STOP instruction will stop the program execution at its current line.



```
Selected project: MyRobotProject
Selected program: PICK_AND_PLACE

0 BASE(1)
1 GOSUB my_label
2
3 STOP
4
5 my_label:
6 RETURN
```

Figure 5-12: Stop instruction

5.6.7 Empty line

It will introduce an empty line to aid readability of code.

5.6.8 Set

Sets either digital or analog outputs to a given value, assign values to a VR or an already declared variable or declare a variable.




Figure 5-13: Set window

Analog output has to set as 12 bit (+/- 10v)



Only pre-configured Digital Outputs will be shown on the Digital Outputs combo box.

VR is an array of real numbers stored in flash memory. The size of the array depends of controller model.

The type of possible variables that can be declare are the next ones:

- Boolean: 1bit binary value (TRUE or FALSE).
- Float: 64bit floating point number.
- Integer: 64bit signed integer value.
- String: ASCII text (1024 characters maximum).

String data type require size as an extra parameter.

Multiple variables can be declare in one instruction separated by commas.




Figure 5-14: multiple variable declaration

If an invalid symbol is inserted or entry ends with a comma the window will show a message and *Apply* button will be disabled.

Assign values or variables value to a variable is also possible in set window. The variable list will be accessible when *Set Var* is selected or through the button *Var* in set variable value window when setting variable or VR value. If the selected variable is STRING datatype it will display a QWERTY keyboard window at the moment of setting its value.




Figure 5-16: Variable list window



Figure 5-15: Set variable value window

5.6.9 Wait

Three types of wait are possible to set:

WHILE ... WEND	MOVE
REPEAT ... UNTIL	SET
FOR ... NEXT	WAIT
IF...ELSE	STRUCTURES

- Wait until motion of selected robot or axis is finished.
- Wait for fixed time in milliseconds.
- Wait for selected input is ON or OFF.




Figure 5-17: Wait window

5.6.10 Structures

Structures instructions are compound by WHILE...WEND, REPEAT...UNTIL, IF...ELSE and FOR...NEXT.

The commands contained in the WHILE...WEND loop are continuously executed until the condition becomes false. Execution then continues after the WEND. If the condition is false when the WHILE is first executed then the loop will be skipped.

The REPEAT...UNTIL structure allows a block of instructions to be continuously repeated until an expression becomes TRUE. REPEAT...UNTIL loops can be nested without limit.

Figure 5-18: Structures submenu

An IF program structure is used to execute a block of code after a valid expression. The structure will execute only one block of instructions depending on the conditions. If multiple expressions are valid then the first will have its instructions executed. If no expressions are valid and an ELSE is present the instructions under the ELSE will be executed.




Figure 5-20: Repeat...Until structure window



Figure 5-21: If...Elseif...Else structure window

WHILE...WEND, REPEAT...UNTIL, IF...ELSE structure instructions can be set by bool condition builder window. It is a wizard that helps users set the condition for structure instructions. The conditions are built in the following format:

variable - relational operator – variable

logical operator

variable - relational operator - variable

...



Figure 5-22: Condition builder window




Figure 5-23: relational operators




Figure 5-25: logical operators

A FOR...NEXT structure is used to execute a block of code a number of times.

On entering this structure the variable (previously declared) is initialised to the value of start and the block of instructions is then executed. Upon reaching the NEXT command, the variable defined is incremented. If the value of the variable is less than or equal to the end parameter then the block of instructions is repeatedly executed. Once the variable is greater than the end value the program drops out of the FOR...NEXT.

FOR...NEXT loops can be nested up to 8 deep in each program.




Figure 5-26: For...Next structure window

5.6.11 APPS

This application can design a conveyer system compare with former palletizer system. There are several blocks to determine some parameters needed in the conveyer and palletizer system.




Figure 5-27: pallet system

Description of each parameters:

- Item_up: The position pick item up
- Item_down: The position pick item down
- First GTA: First GTA in the system
- Last GTA: Last GTA in the system
- Tool Output: The output tool like gripper
- OF item: Offset point on the conveyer
- OF pallet: Offset point on the pallet
- Sensor input: Vision or light sensor input of system
- Middle: The middle point of tool.

6 Settings

6.1 About

In this section it is shown information about the version of the system: controller version, serial number, controller type, Uniplay version and RPS version.




Figure 6-1: About page

6.2 IO configuration

Every system has different IO configuration. In this page it will be possible to address the different physical IOs with RPS.




Figure 6-2: IO configuration

7 Error and warning codes

7.1 Axis status codes

AS_2	Communications error to remote drive
AS_3	Remote drive error
AS_4	In forward hardware limit
AS_5	In reverse hardware limit
AS_8	Following error exceeds limit
AS_9	FS_LIMIT active
AS_10	RS_LIMIT active
AS_12	Pulse output axis over-speed
AS_16	AXIS_FS_LIMIT active
AS_17	AXIS_RS_LIMIT active
AS_21	FEC 26: Robotics runtime 1 hour free limit. Reset the controller

7.2 Robot status codes

RS_0	WORLD_FS_LIMIT active
RS_1	WORLD_RS_LIMIT active
RS_2	ROBOT_FS_LIMIT active
RS_3	ROBOT_RS_LIMIT active
RS_4	TCP_FS_LIMIT active

RS_5	TCP_RS_LIMIT active
RS_7	Robot following error exceeds limit
RS_8	Wrist singularity
RS_9	Alignment singularity
RS_10	Elbow singularity
RS_11	Max speed limit
RS_12	Robot collided

7.3 TPS system codes

TE_0	Jog attempted out of Manual mode. Select Manual mode
TE_1	Jog attempted while E-Stop is pressed. Release E-Stop and enable robot
TE_2	Jog attempted without enable the robot. Press demand button
TE_3	Jog attempted with servo disabled
TE_4	Jog attempted while a program is running
TE_5	Jog attempted while move buffers are not empty
TE_6	Jog attempted in linear while in singularity. Jog in joint mode to go out of singularity
TE_7	Attempting to run a program while E-Stop is pressed. Release E-Stop and enable robot
TE_8	Attempting to run a program without enable the robot. Press demand button
TE_9	Attempting to run a program without enable the robot. Press MOT button
TE_10	Failed to enable the robot

TE_11	Jog speed 0%
-------	--------------

7.4 RPS Architecture codes

RA_0	Error status because E-Stop. Release E-Stop and press reset button
RA_1	Error status because MOTION_ERROR. Press reset button to clear the error
RA_2	Error status because SYSTEM_ERROR. Press reset button to clear the error
RA_3	Error status because MOTOR output is off. Press reset button to clear the error
RA_4	Error status because WDOG turned off unexpectedly. Press reset button to clear the error